



DEPARTMENT OF ENVIRONMENTAL PROTECTION

**PERCHLOROETHYLENE
DRY CLEANER
COMPLIANCE CALENDAR
2014**

Florida Department of Environmental Protection (FDEP)
Division Contacts for
PERCHLOROETHYLENE DRY CLEANERS

FDEP Division of Air Resource Management:

For Dry Cleaner Calendar information, please contact Jessica Dalton at 850-717-9106 or by email: Jessica.Dalton@dep.state.fl.us

For Perchloroethylene Dry Cleaner Air General Permit Registration questions, please contact the Small Business Environmental Assistance Program at 1-800-722-7457 or by email: Small.Business@dep.state.fl.us

FDEP Division of Waste Management:

Federal E. P.A. I. D. #: Tiffany Noland Hazardous Waste Section at 850-245-8727

As a dry cleaner, it is likely that you are a small quantity generator of hazardous waste. Call to obtain your required federal I.D. number.

Dry Cleaning Facility Registration: Rick Vail at 850-245-8856

Dry cleaning facilities and wholesale supply facilities that use dry cleaning solvents are required to be registered with the Division of Waste Management. Regulated solvents include: perchloroethylene (“perc”), tetrachloroethylene, valcene, carbon tetrachloride, and other petroleum-based solvents. The Waste Division issues invoices each November for an \$100 annual registration fee due from every facility that operated in the calendar year. You must be registered in order to purchase perc from your supplier. **If you are a Florida dry cleaner that uses perc, you need to be permitted with the Division of Air Resources Management AND you need to be registered with the Division of Waste.**

Dry Cleaning Solvent Cleanup Program: Jennifer Farrell at 850-245-8937

Dry cleaning facilities and wholesale supply facilities that reported dry cleaning solvent contamination to FDEP no later than December 31, 1998, may be eligible for site rehabilitation assistance. Call for more information on this program and to see if your facility is eligible.

FDEP Division of Water Resource Management—Wastewater Program:

Use an approved waste water treatment device.

Septic tank recommendations: Check with your Local County Health Department

Sewer recommendations: Check with your Local public/private utility

INSTRUCTIONS FOR USE -You may use this calendar to keep records for air program compliance. Keep these records at your facility for 5 years.

(e.g.) **JULY 2014**

PERC PURCHASES RUNNING TOTAL

Total from last month JUNE 2014 (12 Month Running Total)	55
Subtract PERC purchased during July of last year (JULY 2013)	- 10
SUBTOTAL	45

Enter running total from last month.

Enter the amount of PERC you bought during this same month last year, from last year's records or calendar. Subtract that amount.

This is your 12 month running total if you do not buy PERC this month.

Purchase Date of Perc	Purchase Amount in gal.	12 Month Running Total
7/11/2014	+ 15	60
	+	

This is your 12 month running total if you bought PERC this month. Record the bottom number in this column on next month's form in line **TOTAL FROM LAST MONTH**.

Record the date you bought PERC this month, if any.

If you bought PERC this month, record the amount and add it to the subtotal. This amount will also go on next year's calendar for this same month under **SUBTRACT PERC PURCHASED**.

DISCLAIMER: *This calendar is for compliance assistance purposes only. It is not official rule language. Please refer to Chapter 62-210, of the Florida Administrative Code for complete and up-to-date rule language.*

REMEMBER: *Rule for perc dry cleaners requiring the use of a leak detector. For more information please refer to the Code of Federal Regulations 40 CFR Part 63 Air Emissions Standards for Dry Cleaning Facilities.*

CONDENSER TEMP. LOG :

Check the outlet temperature of the refrigerated condenser every week. Record the temperature and date in the space provided. In the block marked "Is temp less than or equal to 45° F (7.2° C)?" Check "Y" or "N" for "yes" or "no". If you checked "N", the machine must be repaired.

INSPECTIONS :

If you buy **140 gallons or more** of PERC per year, you must check your machine weekly for leaks and record the results.

If you buy **less than 140 gallons** of PERC per year, you must conduct and record leak inspections at least every other week.

Record the results of the inspections on the calendar. If leaks are found, they must be repaired within 24 hours. Indicate in the "DATE REPAIRED" block when repairs are completed. If parts must be purchased, indicate the dates they are ordered and the date installed. Parts must be ordered within **2** working days of leak detection and installed within **5** working days of receipt.

CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

JANUARY 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month DECEMBER 2013 (12 Month Running Total)		
Subtract PERC purchased during JANUARY 2013		-
SUBTOTAL		
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total
	+	
	+	

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
	DATE					ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y	N	Y	N	Y
DOORS	N	Y	N	Y	N	Y	N	Y	N	Y
PUMP	N	Y	N	Y	N	Y	N	Y	N	Y
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y	N	Y
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y	N	Y
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y	N	Y
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y	N	Y
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y	N	Y
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y	N	Y
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y	N	Y
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y	N	Y
							LABELED Y N	DATED Y N	COVERED Y N	

JANUARY 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
			1	2	3	4
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
5	6	7	8	9	10	11
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
12	13	14	15	16	17	18
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
19	20	21	22	23	24	25
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
26	27	28	29	30	31	
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	

Tip of the Month:

To reduce solid waste, consider providing hanger caddies for collection, return and reuse.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

FEBRUARY 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month JANUARY 2014 (12 Month Running Total)		
Subtract PERC purchased during FEBRUARY 2013		-
SUBTOTAL		
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total
	+	
	+	

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
	DATE					ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y	N	Y	N	Y
DOORS	N	Y	N	Y	N	Y	N	Y	N	Y
PUMP	N	Y	N	Y	N	Y	N	Y	N	Y
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y	N	Y
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y	N	Y
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y	N	Y
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y	N	Y
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y	N	Y
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y	N	Y
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y	N	Y
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y	N	Y
							LABELED Y N	DATED Y N	COVERED Y N	

FEBRUARY 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
						1
2	3	4	5	6	7	8
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
9	10	11	12	13	14	15
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
16	17	18	19	20	21	22
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
23	24	25	26	27	28	
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	

Tip of the Month:

Reduce paperwork and paper waste by using electronic bookkeeping.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

MARCH 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month FEBRUARY 2014 (12 Month Running Total)			
Subtract PERC purchased during MARCH 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
						ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y				
DOORS	N	Y	N	Y	N	Y				
PUMP	N	Y	N	Y	N	Y				
SOLVENT TANKS	N	Y	N	Y	N	Y				
WATER SEPARATOR	N	Y	N	Y	N	Y				
STILL/MUCK COOKER	N	Y	N	Y	N	Y				
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y				
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y				
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y				
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y				
WASTE CONTAINERS	N	Y	N	Y	N	Y	LABELED Y N	DATED Y N	COVERED Y N	

MARCH 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
						1
2	3	4	5	6	7	8
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
9	10	11	12	13	14	15
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
16	17	18	19	20	21	22
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
23	24	25	26	27	28	29
30	31				Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	

Tip of the Month:

Collect and recycle polyethylene bags.



Have you changed your waste water treatment filter according to the manufacturer's specifications?

CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

APRIL 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month MARCH 2014 (12 Month Running Total)			
Subtract PERC purchased during APRIL 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
						ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y				
DOORS	N	Y	N	Y	N	Y				
PUMP	N	Y	N	Y	N	Y				
SOLVENT TANKS	N	Y	N	Y	N	Y				
WATER SEPARATOR	N	Y	N	Y	N	Y				
STILL/MUCK COOKER	N	Y	N	Y	N	Y				
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y				
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y				
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y				
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y				
WASTE CONTAINERS	N	Y	N	Y	N	Y	LABELED Y N	DATED Y N	COVERED Y N	

APRIL 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
		1	2	3	4	5
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
6	7	8	9	10	11	12
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
13	14	15	16	17	18	19
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
20	21	22	23	24	25	26
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
27	28	29	30			

Tip of the Month:

Collect cardboard, cans and other recyclables at your facility.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

MAY 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month APRIL 2014 (12 Month Running Total)			
Subtract PERC purchased during MAY 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
	DATE					ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y	N	Y	N	Y
DOORS	N	Y	N	Y	N	Y	N	Y	N	Y
PUMP	N	Y	N	Y	N	Y	N	Y	N	Y
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y	N	Y
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y	N	Y
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y	N	Y
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y	N	Y
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y	N	Y
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y	N	Y
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y	N	Y
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y	N	Y
							LABELED Y N	DATED Y N	COVERED Y N	

MAY 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
				1	2	3
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
4	5	6	7	8	9	10
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
11	12	13	14	15	16	17
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
18	19	20	21	22	23	24
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
25	26	27	28	29	30	31
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	

Tip of the Month:

Regularly replace gaskets/seals on dryer dampers, deodorizers and aeration valves.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

JUNE 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month MAY 2014 (12 Month Running Total)			
Subtract PERC purchased during JUNE 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE				
	DATE					ORDERED	RECEIVED	REPAIRED						
HOSES	N	Y	N	Y	N	Y	N	Y						
DOORS	N	Y	N	Y	N	Y	N	Y						
PUMP	N	Y	N	Y	N	Y	N	Y						
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y						
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y						
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y						
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y						
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y						
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y						
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y						
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y						
						LABELED	Y	N	DATED	Y	N	COVERED	Y	N

JUNE 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
1	2	3	4	5	6	7
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
8	9	10	11	12	13	14
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
15	16	17	18	19	20	21
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
22	23	24	25	26	27	28
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
29	30					

Tip of the Month:

Replace faulty or worn gaskets on button trap and around cleaning machine door.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

JULY 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month JUNE 2014 (12 Month Running Total)			
Subtract PERC purchased during JULY 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
						ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y				
DOORS	N	Y	N	Y	N	Y				
PUMP	N	Y	N	Y	N	Y				
SOLVENT TANKS	N	Y	N	Y	N	Y				
WATER SEPARATOR	N	Y	N	Y	N	Y				
STILL/MUCK COOKER	N	Y	N	Y	N	Y				
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y				
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y				
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y				
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y				
WASTE CONTAINERS	N	Y	N	Y	N	Y	LABELED Y N	DATED Y N	COVERED Y N	

JULY 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
		1	2	3	4	5
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
6	7	8	9	10	11	12
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
13	14	15	16	17	18	19
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
20	21	22	23	24	25	26
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
27	28	29	30	31		

Tip of the Month:

After a filter change, check gaskets and sealing of new filter.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

AUGUST 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month JULY 2014 (12 Month Running Total)			
Subtract PERC purchased during AUGUST 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
						ORDERED		RECEIVED		REPAIRED
HOSES	N	Y	N	Y	N	Y				
DOORS	N	Y	N	Y	N	Y				
PUMP	N	Y	N	Y	N	Y				
SOLVENT TANKS	N	Y	N	Y	N	Y				
WATER SEPARATOR	N	Y	N	Y	N	Y				
STILL/MUCK COOKER	N	Y	N	Y	N	Y				
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y				
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y				
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y				
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y				
WASTE CONTAINERS	N	Y	N	Y	N	Y	LABELED Y N	DATED Y N		COVERED Y N

AUGUST 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
					1 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	2
3	4	5	6	7	8 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	9
10	11	12	13	14	15 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	16
17	18	19	20	21	22 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	23
24 31	25	26	27	28	29 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	30

Tip of the Month:

Monitor equipment efficiency (e.g. pounds of clothes cleaned per drum of solvent).



Have you changed your waste water treatment filter according to the manufacturer's specifications?

CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

SEPTEMBER 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month AUGUST 2014 (12 Month Running Total)			
Subtract PERC purchased during SEPTEMBER 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
						ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y				
DOORS	N	Y	N	Y	N	Y				
PUMP	N	Y	N	Y	N	Y				
SOLVENT TANKS	N	Y	N	Y	N	Y				
WATER SEPARATOR	N	Y	N	Y	N	Y				
STILL/MUCK COOKER	N	Y	N	Y	N	Y				
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y				
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y				
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y				
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y				
WASTE CONTAINERS	N	Y	N	Y	N	Y	LABELED Y N	DATED Y N	COVERED Y N	

SEPTEMBER 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
	1	2	3	4	5	6
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
7	8	9	10	11	12	13
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
14	15	16	17	18	19	20
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
21	22	23	24	25	26	27
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
28	29	30				

Tip of the Month:

Size loads (neither over nor under-loading) to maximize solvent efficiency.



Have you changed your waste water treatment filter according to the manufacturer's specifications?



CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

OCTOBER 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month SEPTEMBER 2014 (12 Month Running Total)			
Subtract PERC purchased during OCTOBER 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE				
	DATE					ORDERED	RECEIVED	REPAIRED						
HOSES	N	Y	N	Y	N	Y	N	Y	N	Y				
DOORS	N	Y	N	Y	N	Y	N	Y	N	Y				
PUMP	N	Y	N	Y	N	Y	N	Y	N	Y				
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y	N	Y				
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y	N	Y				
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y	N	Y				
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y	N	Y				
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y	N	Y				
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y	N	Y				
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y	N	Y				
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y	N	Y				
						LABELED	Y	N	DATED	Y	N	COVERED	Y	N

OCTOBER 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
			1	2	3	4
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
5	6	7	8	9	10	11
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
12	13	14	15	16	17	18
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
19	20	21	22	23	24	25
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
26	27	28	29	30	31	
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	

Tip of the Month:

A tiny drip or leak through a door gasket valve, or bearing seal may add to many gallons of solvent \$\$\$ in a very short time.



Have you changed your waste water treatment filter according to the manufacturer's specifications?

CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

NOVEMBER 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month OCTOBER 2014 (12 Month Running Total)			
Subtract PERC purchased during NOVEMBER 2013			-
SUBTOTAL			
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total	
	+		
	+		

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
	DATE					ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y	N	Y		
DOORS	N	Y	N	Y	N	Y	N	Y		
PUMP	N	Y	N	Y	N	Y	N	Y		
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y		
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y		
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y		
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y		
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y		
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y		
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y		
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y	LABELED Y N	DATED Y N COVERED Y N

NOVEMBER 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
						1
2	3	4	5	6	7	8
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
9	10	11	12	13	14	15
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
16	17	18	19	20	21	22
					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	
23	24	25	26	27	28	29
30					Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	

Tip of the Month:

Open button traps and lint gaskets only long enough to clean.

Clean lint screens regularly to avoid clogging fans and condensers.



Have you changed your waste water treatment filter according to the manufacturer's specifications?

CONDENSER TEMPERATURE LOG

PERC PURCHASES RUNNING TOTAL

DECEMBER 2014

Date	Temperature	Is Temp less than or equal to 45°F (7.2°C)?
		Y/N
		Y/N
		Y/N
		Y/N
		Y/N

Total from last month NOVEMBER 2014 (12 Month Running Total)		
Subtract PERC purchased during DECEMBER 2013		-
SUBTOTAL		
Purchase Date of Perc.	Purchase Amount in gal.	12 Month Running Total
	+	
	+	

REMINDER:
IF YOUR 12-MONTH RUNNING TOTAL IS 140 GALLONS OR MORE OF PERC, YOU MUST CONDUCT AND RECORD LEAK INSPECTIONS WEEKLY.

INSPECTED	LEAKING?					DATE PARTS		DATE PARTS		DATE
	DATE					ORDERED	RECEIVED	REPAIRED		
HOSES	N	Y	N	Y	N	Y	N	Y	N	Y
DOORS	N	Y	N	Y	N	Y	N	Y	N	Y
PUMP	N	Y	N	Y	N	Y	N	Y	N	Y
SOLVENT TANKS	N	Y	N	Y	N	Y	N	Y	N	Y
WATER SEPARATOR	N	Y	N	Y	N	Y	N	Y	N	Y
STILL/MUCK COOKER	N	Y	N	Y	N	Y	N	Y	N	Y
HALOGEN LEAK DETECTOR	N	Y	N	Y	N	Y	N	Y	N	Y
DIVERTER VALVE/EXHAUST DAMP	N	Y	N	Y	N	Y	N	Y	N	Y
GASKET/DOOR LINT/BUTTON TRAP	N	Y	N	Y	N	Y	N	Y	N	Y
CARTRIDGE FILTER/SPIN DISC	N	Y	N	Y	N	Y	N	Y	N	Y
WASTE CONTAINERS	N	Y	N	Y	N	Y	N	Y	N	Y
							LABELED Y N	DATED Y N	COVERED Y N	

DECEMBER 2014

Use your halogen leak detector weekly to detect Perchloroethylene (PERC) leaks and maintain records.
 The Halogen hydrocarbon detector is a portable device that must be capable of detecting PERC vapor concentrations of 25 ppm by volume.



SUN	MON	TUE	WED	THU	FRI	SAT
	1	2	3	4	5 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	6
7	8	9	10	11	12 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	13
14	15	16	17	18	19 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	20
21	22	23	24	25	26 Temp Logged <input type="checkbox"/> Inspect Logged <input type="checkbox"/>	27
28	29	30	31			


Tip of the Month:

Install energy efficient fluorescent lighting such as T8, T10 fixtures and bulbs, and electronic ballasts or metal halide and/or sodium vapor lamps. Recycle old lamps containing mercury.



Have you changed your waste water treatment filter according to the manufacturer's specifications?

Dry Cleaner: District and County (Local) Air Program Contacts



Contact Person	Office	Location	Telephone #
Carol Melton Chris Stoll	Northwest District	Pensacola	850/595-0616 850/595-0654
Tracy White	Northwest District Branch	Tallahassee	850/488-3704
Marc Lovallo John Phillips	Northeast District	Jacksonville	904/256-1700 904/256-1549
Erin DiBacco	Southwest District	Tampa	813/470-5900
Sirena Davila	Central District	Orlando	407/897-2958
Patricia Tampas	Southeast District	West Palm Beach	561/681-6621
Robert Stewart Wayne Lewis	South District	Fort Myers	239/344-5699 239/344-5662
Ray Gordon	Miami-Dade County	Miami	305/372-6925x6924
Clifton Bittle Paul Shelton	Broward County	Plantation	954/519-1208 954/519-1444
Bill Coffman	Duval County	Jacksonville	904/255-7181
Jason Waters	Hillsborough County	Tampa	813/627-2600x1269
Robert Gallo Jeff Dizek	Palm Beach County	West Palm Beach	561/837-5928 561/837-5925
Shea Jackson Jeff Morris	Pinellas County	Clearwater	727/464-4422
Ilka Bundy	Orange County	Orlando	407/836-1476
Michael Storino	Sarasota County	Sarasota	941/861-6221



ATTENTION:

The Perc Dry Cleaner Air General Permit is ***NOT TRANSFERABLE*** and does not follow a change in ownership of the facility. If you are a new owner and have not submitted a registration worksheet and/or have any permitting questions, please contact the **Small Business Environmental Assistance Program** at **1-800-722-7457**

It is the seller's responsibility to notify the FDEP, Division of Air Resource Management of the pending change in ownership. Likewise, it is the responsibility of the new owner/company to submit a new PERC Dry Cleaner Air General Permit Registration (or required information) no later than 30 days prior to the sale. You can **register online** electronically at:

<http://www.dep.state.fl.us/air/emission/agpers.htm>

If you prefer to register manually by hardcopy, then print the "Perc Dry Cleaner Air General Permit Registration Worksheet" located at:

<http://www.dep.state.fl.us/air/emission/drycleaners.htm>

Registrations and fees should be mailed to the following address:

**FDEP Receipts
P.O. Box 3070
Tallahassee, FL 32315-3070**

